



# JOHNNY G SPIRIT BIKE


## KINOMAP CONNECTION GUIDE




Download and install Kinomap app on IOS or Android devices.




Create an account as directed by app or Login to your profile.




Continue to **SETUP MY PROFILE**.




Set up profile.




Continue and select equipment




Select **SPIRIT**.




Select **JOHNNY G SPIRIT BIKE**.




Select appropriate Bluetooth signal.




Review setup and press **START**.




Option to **FIND FRIENDS** or **TRAIN**.




Choose training mode.




Select a free cycling video. Subscribe for more content.



Course overview.




Select **TRAINING MODE** and press **START**.



Link complete.

User data appears in upper corner. Increasing **WATTS** output increases your ride speed. Increasing the bike's resistance level and cadence will increase watts.



If desired, modify profile or training settings.



## JOHNNY G SPIRIT BIKE

### KINOMAP CONNECTION TROUBLESHOOTING

If having difficulty connecting your Johnny G Spirit Bike to the Kinomap app, follow the steps below to clear and establish a Bluetooth connection.

- If Bluetooth not connecting, check to see if the bike BT is connected to another device (tablet or phone, watch, etc.). Use option to Forget This Device to end a connection.
- Turn off then turn on BT switch in the settings menu of IOS or Android device.
- Reset the bike console (press and hold the PLAY and + keys simultaneously for 3 seconds), bike displays CONSOLE RESET.
- When the console resets, all the connections are reset...just like when you restart your computer.
- If bike does not automatically pair, check connection in Equipment Management to see if mph, rpm, watts and bpm are being displayed and then save.